




GeeGee
G A M I N G
CASES

Model: EDGE ◀
Serie: EDGE G1

EDGE case - User Manual

v1.0

Package content	2
Warranty	3
Safety information	4 - 5
Starting	6 - 7
Technical information	8 - 9




Congratulations on the purchase of your GeeGee gaming EDGE Case. Our EDGE case is designed to be used with the SONY PS5 DIGITAL and DISC. GeeGee gaming's high-quality products are manufactured with the greatest care. Please read and follow these instructions carefully to get the most out of this product. If you are missing any parts or have other issues with the case, please contact us.



Instruction manual

1 x instruction manual



Powersupply cord

1 x C13 cable 1,5m



Monitor release tool

1 x Monitor release tool



GeeGee EDGE case

Including 24 inch AOC gaming monitor (fitted)

Including USB hub (fitted)



Operating Guidelines

Do not turn on the PS5 or have it turned on when the gaming case is closed! This may result in overheating and potential fire hazard! When connecting to the power supply, please use only the supplied or identical power cords and powercords that are compatible with the power supply connection values below.



WEEE:

In European countries where the WEEE directive applies, do not dispose of the case or any contained components as household waste. Please only dispose the case at designated electronic waste collection points.



Warranty:

Any modifications to the case or its parts will void your warranty. This also applies to the incorrect or negligent handling of the product. Any manipulation or removal of the serial number or damages from Force Majeure shall also void the warranty.



Responsibility:

GeeGee gaming is not liable for damage to the case due to improper handling.



Packing:

This box (packaging) is recyclable. Please recycle according to local regulations.

Safety first

Read through the safety information before you operate the product. To prevent short circuits, please only use this product in a dry environment. Do not expose the components to continuous rainfall or moisture. Do not use it next to or in the vicinity of baths, swimming pools etc. Do not expose the case and/or your system components to high temperatures or to powerful sources of light. All openings in and on the case serve the ventilation of the installed electronic equipment (monitor, game consoles etc.). Do not block them off and ensure that ventilation is adequate at all times. Only use the product with the supplied original components/appliances and with the game consoles indicated as compatible in these operating instructions.



The product is only designed to carry compatible game consoles and other supplied appliances, components and for operating them in keeping with the specifications of these operating instructions. You risk losing any guarantee or warranty claims if you use the product contrary to its intended purpose or if you modify the product or carry out repairs on it yourself. GeeGee gaming only provides guarantees on the basis of a separate guarantee statement and only to the extent set out therein.

Operating temperature

5-35°C

Connecting power

When connecting to the power supply, please use only the supplied or identical power cords and power cords that are compatible with the power supply connection values below. The use of other power cords may result in damage to the product, the loss of any guarantee and health risks for the user. This appliance is connected to the local power supply (please make a note of the connection instructions and any centre. Unplug the power cord during thunderstorms or long breaks in operation. This protects the entire system from power surges.

Power cord



Powersupply: AC 220-240 V 50/60 Hz
Cable type: C13

Daily operation

The case must be kept open when in operation. Do not shut the case during usage to prevent heat warranty claims by only operating the case when it is open.

Clean the case with a dry cloth. A slightly damp cloth can be used to remove any coarse dirt, but only on the outside of the case. Do not use any corrosive cleaning agents or chemical stain removers.

Separate instructions

Please also observe the separate operating instructions for the installed monitor.

<https://eu.aoc.com/nl/gaming/products/monitors/24g2su-bk/downloads>

Installing the PS5

1. Place the PS5 in the case and hook on the HDMI, ethernet and power cable to the PS5.



- Use the red slider to keep the PS5 in place.
- 3.



2. Slide the PS5 in the case under a slight angle.



First steps when using the EDGE case

Before you begin:

Make sure the case is standing firmly and is not set up right next to water (pool, etc.).

Follow the next steps in order.

1. Place the case (without trolley) on a firm base (e.g. table).
2. Open the case and gently push the lid upwards into the operating position.
3. Take the power cord from its compartment; plug it into the back of the case and connect it to a power socket.
4. Switch on the PS5 at the mains switch. The charging station and USB hub are now operable.

Troubleshooting monitor problems.

In case of problems with the monitor, please follow these steps.

1. Make sure all cables are connected to the console and power supply.
2. Check if the monitor power light is on, this can be found next to the power button on the bottom of the monitor.
3. If the light is on (red), press the power on button, when it the light turns green make sure u are using the correct source in on the monitor.
4. In case of a power light that is not burning, double check all power connections.
5. Please contact us (www.geegee-gaming.com) if the monitor still does not work after following these steps.



Connections

Internal connections

Power supply cable IEC C13 female: AC 220-240 V 50/60 Hz (insert cable end into PS5)

HDMI connecting cable (insert cable end into PS5)

Ethernet connecting cable (insert cable end into PS5)

External connections

IEC C14 male connector/ Power supply

Ethernet connection point

Monitor Data

24 inch / 1 ms / 165 Hz / Full HD

Monitor audio

External measurements of case

Dimensions: 590 x 365 x 145 mm (D x W x H), without attachments

EU Declaration of conformity

We, the undersigned, **GeeGee Gaming, Willem Buytewechstraat 147, 3024XE, Rotterdam** declare, under our sole responsibility, that the product: **GeeGee EDGE G1 Case** is in conformity with the provisions of the relevant EU harmonisation legislation: **2014/30/EU | 2014/35/EU | 2009/125/EC | 2011/65/EU | 2012/19/EU**

NEN-EN 55032:2015, Class B; EN 61000-3-2:2014; EN 61000-3-3:2013;
EN 55024:2010+A1:2015; EN 60950-1:2019+A11:2020; EN 61558-1:2005+A1;
EN 61558-2-16:2009+A1; EN 301 489-1:2019-03 Regulation (EC) No. 1275/2008

Rotterdam, 01/10/2022



Signature GeeGee Gaming

Rights Copyright 2022: GeeGee Gaming – All rights reserved.

GeeGee EDGE and GeeGee gaming are brand names of The challenge room B.V. which are registered in the EU and other countries. Playstation is a protected and registered brand name of the Sony Co. and is only used here to refer to the designated purpose of the GeeGee gaming products in association with Sony products.





GeeGee
G A M I N G
CASES

Support:
Warranty:

www.geegee-cases.com
info@geegee-cases.com